



1. Let the plastic connector of ropes insert into the hole of the tent
2. Lock screw very tight
3. Make sure the bottom of the tent wrap nest swing

