



Step 1:

Slot the top pole into the middle pole, and attach the bottom pole to the other end of the middle pole.

Step 2:

Thread the guy line through the hole in the top pole and secure both ends to the ground with the ground nails. Make sure to pull tight.

Step 3:

Tie the top and bottom of the net around the top poles of both side. Make sure to secure tightly to avoid the net falling in the middle.

- 1.将顶杆插入中杆，并将底杆连接到中杆的另一端。
- 2.将拉线穿过端杆上的孔，并将两端固定到地面上钉子.安装一定要拉紧。
- 3.把网的顶部和底部绑在两个网柱的顶部侧面制造一定要扎紧，以免网掉在中间。