

Note: Before using, please read the manual and keep it for future reference. Other prospective users should every time receive the sledge together with the manual.

VT-Sport FOLDING SLEDGE (HKS 43100, DKS 63100, DKV 73100, HKV 53100)



USER MANUAL

Simple unfolding and folding and small size of the VT-Sport sledge provide for easy transport in a car trunk and hassle free storage at home. The sledge construction facilitates easy unfolding and folding, and at the same time it excludes any possibility of using the sledge when the seat is not properly secured. A patented automatic lock prevents any unintended folding while sledging.

Our product is safe for children to enjoy sledging for many seasons, **provided** it is used as intended and according to guidelines included in the manual.

- Due to limited manoeuvring and braking, the sledge can be used by children of 3+.
- Children up to 7 should use the sledge under supervision of an adult.
- Younger children may be towed or slide on the sledge from gentle hills and in quiet surroundings of no intensive traffic, and **under continuous supervision** of an adult person.
- Maximum load is 75 kg.
- **The sledge is not professional equipment.** It can be used on snow only. It cannot be used on jumps or tracks! Slide down gentle slopes only, and pay attention to people, trees, stones and other obstacles.
- For safety reasons, any changes to the construction are prohibited.
- The sledge can not be towed behind vehicles.
- In case of damage, any use of the sledge should be discontinued.
- Legs should not be placed inside the sledge, but instead directed forward and placed on the two runners to enable manoeuvring and braking.
- Extreme slabs of the seat should be used to hold oneself while sliding downhill as well as to unfold and fold the sledge.
- Loosely fitted cloths and hanging scarves should be avoided. There is a risk of suffocation.
- It is recommended to use personal protection such as hard boots, helmet, guarding pads, and gloves.
- The sledge should be unfolded and folded by adults only.
- **Unfolding and folding should be made according to guidelines below to exclude any risk of fingers shutting.**

Unfolding:

- Hold extreme slabs of the seat and pull them to the outside (fig. 1) until the sledge is unfolded completely and a click of the lock can be heard.
- Check whether the bolt of the lock is safely placed in the opening (fig. 2) and prevents folding unless the lock is open.

Folding:

- Put the sledge on a side and pull the bolt out using a handle under the back piece of the seat, at the same time the extreme slab of the seat should be pressed (fig. 3) to fold the sledge completely. The two parts of the sledge should adjoin (fig. 4).

Cleaning and maintenance:

- After using, the sledge should be dried with a cloth or paper towel.
- Metal runners should be protected by rubbing oil or vaseline.
- The sledge should be kept in a dry and airy place.
- Each time before using, the sledge should be checked against damage and wear and tear.
- Each time before using, the safety lock should be checked.
- Any repair or part replacement should be made by a specialist workshop, preferably using original parts provided by the manufacturer. Please contact the manufacturer or an importer at the address below.

Accessories available on order:

- **backrest:** A backrest can be attached to the VT-Sport sledge. Fitting according to a manual attached to the backrest.
- **bag** for the HKS folding sledge
- **bag** for the DKS folding sledge

Spare parts:

- lock in the back part of the seat
- metal piece linking a beam with a cross piece
- wooden link

Name and address of manufacturer/distributor can be found on packaging.