

To activate shock-absorbing Antishock

Feature and adjust Middle Section length

1. Grip Upper Section in left hand and Middle Section in right hand.
2. To open, twist Upper Section away from your body.
3. Extend or retract Middle Section to desired length.

CAUTION: DO NOT extend Middle & Lower Sections beyond **STOP**.

4. To close, twist Upper Section toward your body.

To adjust Lower Section length:

1. Grip Middle Section in left hand and Lower Section in right hand.
2. Twist Lower Section toward your body.
3. Extend or retract Lower Section to desired length.
4. To close, twist Lower Section away from your body.

Tip options:

1. Use Standard Tip on level ground.
2. Attach Umbrella feature for snow or sand. Insert Tip into Umbrella and twist to tighten. Replace standard Tip.
3. Remove Standard Tip to expose Metal Tip for wet or icy conditions. Umbrella may remain attached or remove it.

TIPS FOR USING

The heart of MBC adjustment/locking system is the proven "expander".

The internal, split dowel "expands" (locks)

when pole sections are twisted clockwise, and unlocks (for adjusting) when twisted counter-clockwise.

Pole sections only need a few turns to be fully locked or unlocked. With 3-section poles, fully extend the lower shaft to the "STOP" mark then adjust to the desired length using the middle section.

NEVER ADJUST ANY OF THE POLE SECTIONS BEYOND THE "STOP" MARK!

CARBIDE FLEXTIP

MBC exclusive carbide flextip system is designed for many miles of secure performance on all terrain and reliably protects the lower shaft

from damage (if caught or stressed up to a 15° angle) the flextip may

be changed easily if broken or worn by simply knocking it off the shaft with a quick snap, apply new tip and tap down to secure.

It is recommended that you carry a spare flextip(s) in your pack during

any hike. New, threaded baskets can be easily changed for different seasons

used by turning on/off. Please remove the transparent tip protectors before

using the poles. They are only for protection while shipping.

For walking on pavement or indoors we recommend our rubber tip attachment (accessories).

POSITIVE ANGLE

The 15 degree Positive Angle corrects the position of the wrist while planting the pole.

Allows your wrist to stay in a neutral position while gripping the pole. This is

more comfortable and helps absorb shock. The P.A. also improves the handing of the pole.

Your hand can maintain a stronger grip through the entire poling motion for constant control and security.

3 YEAR PARTS SERVICE WARRANTY

The 3 Year Parts/Service Warranty gives every MBC consumer the security that we will stock accessories and spare parts available for the next 10 years. Our good name stands behind it.