



**User Instructions** 

**How To Start** 

#### Notes

Step 2 may be neglected since the initial momentum can be generated by certain gestures further on



Gently place your leading foot on the middle of the front board.

### **How to Propel Swing Gesture**





Twist your hip and legs to swivel clockwise as illustrated.

### Twist Gesture



Press the front board with the tip of your front foot and simultaneously press the rear board with the heal of your rear foot as illustrated.





## **General Warning**

- 1. Information about the construction of Power Surfer
- a. Regarding use of non-jd bug products with your jd bug Power Surfer. Your Power Surfer has been built to jd bug design specifications. All the original equipments supplied at the time of sale were selected on the basis of their compatibility with the frame, wheel and all other pants.
- b. Certain after-market products may or may not compatible with your jd bug Power Surfer. Unsuitable modification can bring you a hazard! Consult your retailer or call jd bug prior to modifying or replacing any component with a non-factory specified product.
- C. Power Surfer riding can be hazardous activity. Power Surfer can, and are intended to move and it is therefore possible to get into dangerous situations and/ or lose control and/ or fall off. If such things occur you can be seriously injured or die.

  Like any other moving product, using a Power Surfer can be a dangerous activity and may result in injury or death even when used with proper safety precautions. Use at your own risk and use common sense.

#### 2. Instruction for use

- a Use the Power Surfer only on smooth, dry, level ground without loose debris, such as rocks or gravel.
- b. Do not exceed 220 pounds (100 kilograms) total weight on the Power Surfer.
- C. Like any other moving product, riding Power Surfer can be an dangerous activity and may result in injury or death even when equipped with proper safety precautions. Use at your own risk and use common sense.
- d. Always wear proper protective equipments, such as helmet, elbow pad and kneepad. Gloves, long sleeve shirt, long pants and athletic shoes are recommended for enhanced protection.
- e. Avoid speed bumps, sand, gravel and anything else that could cause your wheels or stop. When in doubt, avoid the bumps.

- •f. Do not allow children under age eight (8) to use Power Surfer along. Children under this age should ride with adult supervision at all times.
- 9 Never ride in traffic or on the street and watch your surroundings for pedestrians, bikes, and skateboard and Power Surfer riders. Use the Power Surfer in areas free from fixed or moving hazards, such as poles, curbs, hydrants, walls, parked automobiles and traffic.
- h.please check screws and fastening regularly and replace new one if necessary.
- Tighten all bolts, and make sure the steering tube, steering tube extension, and handlebars are locked in place before riding.
- •j. Wheels and bearings Under normal circumstances and conditions, jd bug wheels and wheel bearings are maintenance free. Nonetheless, it is the responsibility of the owner or guardian to periodically inspect the wheels for wear and tear, the axle for proper tightness, and bearings for side-to-side play and loose parts.

When a wheel or wheel bearing develops play, this is an indication of excess wear and replacement is necessary. Replace immediately with only genuine jd bug wheels.

Worn tires/wheels/bearings are considered normal wear-and-tear and are not covered by the jdbug limited warranty. Wheels other than genuine jdbug wheels may not be compatible with your jdbug Power Surfer. The use of anything other than genuine jdbug replacement parts may affect your safety.

- k. Avoid water, speed jumps, sand, gravel and anything else that could cause your front wheel to stop. Bumps have the potential to stop the front wheel. When in doubt, avoid the bumps.
- I. Learning tricks step by step, any not familiar skills will cause injury when learning.
  In addition, for beginner, for safety reason, partners or parents always stay near around.
- •mBefore use, please inspect any sharp edge which may caused through used, and please remove it.
- Before use, please inspect Power Surfer, if find any splinters and cracks, please replace it when needed.
- 3. Servicing & Maintenance Instructions
  - a.Always Inspect Power Surfer Prior Toriding.Properly inspecting and maintaining your Power Surfer can reduce the risk of injury. Always inspect your Power Surfer before riding and regularly maintain it.

#### 4. Power Surfer Safety Code

- a. Never use Power Surfer at dust or night or in wet or icy conditions.
- b.Always check the local laws regarding how and where to legally use the Power Surfer.

- C. Aggressive and other stun-type riding reduce your ability to maneuver and contral the Power Surfer. In addition to wear appropriate protective gear, serious attention and caution must be paid for safe operation. Failure to follow the warning increases risk of serious injury.
- d.Running or Jumping onto board can be dangerous and might cause any serious injures.

# **Product Introduction**

The Power Surfer is a derivative of a skateboard and is similar to a caster board with inclined caster wheels. It consists of two main boards that provide elasticity during motion, as well as a metal strut connected underneath the boards for its rigidity. The user may repeat certain actions to twist the Power Surfer in order to propel and cruise in desired direction without setting feet on the ground. The Power Surfer also has an assistant wheel set attached on its strut to help maintain user's balance while the twisting activity.



120° Inclined Caster Wheels

Power