

ASSEMBLY INSTRUCTION

Step 1

Spread the inner tent on the floor. Insert two F/G poles into pole sleeves and cross them over each other. (see fig. 1, 2)

Step 2

Insert the ends of the F/G poles into plastic holder. (see fig. 3)

Step 3

Insert peg through D-ring into the ground on four corners to secure inner tent to the ground. (see fig. 4)

Step 4

Tie straps on the top where the F/G poles cross. (see fig. 5, 6)

Step 5

Place the outer tent over inner tent, tie straps to poles. (see fig. 7)

Step 6

Use pegs to fix the outer tent into ground through holes of elastic shock cord. (see fig. 8)

Step 7

Open the zip of outer tent and fold out the entrance awning, and then insert the two steel poles at its corners. Fasten the guy ropes to the steel pole ends and anchor them to the ground with the tent pegs. (see fig. 9)

Step 8

Locate the pre-fixed guy ropes and peg them down so that there is even tension all round the tent. The length of the ropes can be adjusted. (see fig. 10, 11)

Step 9

Tent after assembly. (see fig. 12)

Package contents

Component	Quantity
Tent bag	1
Pole bag.	1
Peg bag	1
Outer tent	1
Inner tent	1
F/G poles	2
Steel poles	2
Guy ropes	6
Metal Pegs	23




Fig. 1




Fig. 2



Fig. 3




Fig. 4




Fig. 5



Fig. 6




Fig. 7



Fig. 8



Fig. 9




Fig. 10



Fig. 11



Fig. 12