
## 2460CCER GAME INSTALLATION MANUAL







Must assure the product is completely correctly assembled according to the instruction before using. (Assembly tools is inclusive in the box)
The process of assembly must be done by adult or under direction by adult.

## COMPONENTI:


Number	Qty	Number Qty		Home Team			
A1	X2	B1	0	X12	T1	å	<b>X</b> 9
A2	X2	B2	<b>③</b>	X2	Away Te	am	
A3 (6.5cm)	X4	В3		X6	<b>T</b> 2		<b>X</b> 9
A4 🥡 (3cm)	X4	B4	$\bigcirc$	X6			
A5 🛛 Ф 🖟	X1	B5 ()	(2.6m	m) X6			
A6 📎	X2	В6 (∮	(3r	nm) X4			
A7 🐃	X2	В7 €	<b>=</b>	X1			
A8	-X6	_B8 <b>∮</b>	(2.5mm)	X18			
		B9 🌬		nm) X4			




Long side with the short side of the diagram assembly.




Install balls plates.




Install the handle.




Inserted into the long side of the club in order.




Additional one long side installation.




On both sides of the fixed live.




Install the handle.



Secured with screws.



Install ball box and secured with screws.



Install the scoreboard.