ITEM.NO.: 207

Please read this manual before use.

## **Folding Scooter**

This scooter is to be assembled by an adult.


Warning! Not suitable for children under 5 years. Choking hazard due to small parts.

Check all parts & fixing are secure before allowing a child to ride this scooter.


Not for children with a body weight of more than 50kgs.

Warning! Protective equipment should be worn. 50kgs max.

Use only under constant adult supervision.



To fit grips, insert handle bars into the T-bar and make sure that the spring button pops out to secure in position properly.




To adjust the stem, release the quick lock and press the spring button, then adjust the handlebar at 3 height levels properly.

The button must be then pop into the fixation hole.


Tighten the quick lock to secure the handlebar.

After use, simply loosen the quick lock, press the spring button and push down the handlebar.


Tighten the quick lock to secure the handlebar.



The screw must not be taken out.
If you lose this screw, do not use until
the screw has been replaced.




To unfold scooter, release the quick lock.



Pull the plastic lever upwards to unlock the system.



Warning! When folding the scooter, ensure that the front wheel aligned to the scooter body. If it is not done, it will not close properly. Keep fingers away from all moveable parts be the scooter as fingers could get trapped.



E III

## **Operation Manual**

- 1.Grip the handlebars with your hands, place one foot on the board and the other foot on the ground.
- 2. Pay attention to your surroundings and make sure that your riding areas is clear.
- 3. Kick backgrounds with your foot beside the scooter to give you motion.
- 4. Repeat this kicking action in order to stay in motion.
- 5. To stop or slow down, place your kicking foot on the brake peddle above the rear wheel or put your kicking foot on the ground.
- 6. Do not over steer as this could cause you to fall off the scooter.

- 1. After use, wipe the product with mild detergent.
- 2. Do not leave this product in high temperatures, intense sunlight or dusty areas.
- 3. Store in a dry space.



- Important Safety Notice:

  1. The product is recommened for user of 5 years and up.
- 2. After checking that all parts are in good condition, remember to check that all the screws and wheels are tight before use. Pay attention all locking devices are engaged.

  3. Protective equipment should be worn such as helmet, glove, knee pads
- and elbow pads.
- 4. The scooter must only be used one rider at a time.
- 5. Do not use this product for jumping stunts or tricks. The scooter is not designed for such use.
- 6. This product is not a road vehicle and should be used for leisure purposes only.
- 7. Do not use this product during poor weather (rain, snow, poor visibility) or around heavily populated areas (pavements, streets, highways, muddy areas, rocky surfaces and slippery surfaces). It will cause dangerous. We recommend that you use this product in a park or other open space.
- 8. Do not take this product apart.
- Requires great skill, so as to avoid fails or collisions causing injury to the user and third parties.

## Warning:

The scooter is not designed to be dropped when not in use. If the scooter is dropped after use, over a period of time you will damage the plastic end piece, the foam and the tubing. If you damage this part of the scooter, it is strongly advised that you replace the damaged parts as soon as possible to avoid any accident caused by making contact with these parts.

It is strongly recommended that you wear protective equipment whilst using this product and the scooter should not be used on any other surface other than on flat even ground. It is not designed for graveled roads, on grass surfaces or any other uneven surface as this could cause not only damage to scooter but also the rider.

