

Ages 9 and up
36-72kg

TWIN STICK POGO



Introduction


Have fun! Get out and jump with your Twin Stick Pogo.

Before you begin

Once you've opened the package, make sure you have:

- Twin Stick Pogo (no assembly required)
- Instruction Sheet

Quick start



RIGHT WAY TO JUMP:

Start by holding the Pogo Stick in a vertical position. Balance on stick by placing feet on foot pads and hands on grips. Pull up on the grips while jumping.



WRONG WAY TO JUMP:

Do not push the Pogo Stick away from you as you may lose your balance. Keep vertical position.

Safety

This product should be used with caution as it requires some skill to balance and jump. Avoid falls or collisions which may cause injury to consumer or third party and/or damage the product.

- This product was designed for children 9 and up, not exceeding 160 lbs weight.
- Check the Pogo Stick regularly for wear. Do not use the Pogo Stick if it is damaged or broken.
- Always wear safety equipment including helmet, knee pads, elbow pads, gloves. Always wear closed shoes (sneakers recommended) when using the Pogo Stick.
- Avoid jumping on surfaces with water, sand, dirt, gravel.
- Do not use the Pogo Stick if the rubber tip has been removed.

Always wear protective gear including helmet, knee pads, elbow pads, wrist guards and closed shoes.