

## INSTRUCTION MANUAL

Stop Watch 87




### Operation Manual

Sport Timer with alarm, chronograph, 1/100 sec, lap & split control

#### Features:

1. Hour, Minute, Second & Day of the week.
2. Month & Date.
3. Chronograph with 1/100 second, with lap/split control.

4. 4 year Calendar.
5. Beep, Beep alarm with & snooze.
6. 12/24 hour display for user's option.
7. Maximum counting: 23 hours, 59 minutes, 59 second.



## Switch Control

Normal readout: Hour, Minute, Second & day of the week.

1. Press and hold #1 to see Month/Date
2. Press and hold #2 to see Month/Date.
3. Press #3 to see Mode control for chronograph function
4. Then press #3 to set Alarm
5. Again press #3 to set Normal Time
6. Again press #3 to see Normal Time readout

Setting operation:

Normal Time:

1. Press #3 3 times to get normal time setting mode. The 'second' will start flashing. Press #1 to set the seconds
2. Press #2 to see „Minute“ flashing, press #1 to advance Minute.
3. Press #2 to see „Hour“ flashing, press #1 to advance Hour
4. Press #2 to see Date flashing, press #1 to advance Date
5. Press #2 to see Month flashing, press #1 to advance Month.
6. Press #2 to see Day of week Flashing, press #1 to advance day of week
7. Finally, press #3 once to return to normal time readout

12/24Hour Option

While setting 'hour', 12/24 hour readout may be obtained by turn around cycle, i.e. AM/PM in 12 hour format and 'H' in 24 hour format.

Alarm Time:

1. Press #3 twice to get the alarm time „Hours“ to start flashing, press #1 to advance.
2. Press #2 once to get alarm time minute to start flashing, press #1 to advance.
3. Finally, press #3 once to return to normal time readout.

Chronograph:

1. Press #3 to get into the Chronograph mode, by pressing #1, you can now start or stop on any counting event.
2. During counting, press #2 will enter into lap time mode, meaning that 1 portion of the counting is registered on the display while the counting is still going on in the background.
3. Press #2 will get you to the current counting.

Alarm Function:

1. The function of the alarm can be armed or disarmed by pressing and holding #2 then pressing #1 together.
2. When alarm is on, it will display a bell on the upper right corner of the display.
3. When the alarm bell is on, and the normal time approaches the alarm time, the alarm will sound.
4. The alarm will stop itself after 60 seconds, or can be silenced by pressing #2. In either case, the alarm will sound again at the same time of next day.

Snooze Function:

1. When alarm beep, beep is on, pressing #1 will enter into a snooze function. It means that the alarm will sound again after 5 minutes if not disabled by pressing #2.

Battery:

For battery replacement, use LR44 or equivalent.