



USER 'S MANUAL FOR :

# THE 2 UNIT OUTDOOR PLAY GYM

SPSE-1575-2

SWING

SWING



Dimensions in mm

Assembly, Installation, Care, Maintenance and Use Instructions

Manual depicts typical installation - your model may differ from illustrations

**READ THIS FIRST!!!**

**Thank you for purchasing our product**


**IN CASE OF MISSING OR BROKEN PARTS,  
PLEASE CONTACT PLACE OF PURCHASE  
FOR ASSISTANCE.**

**Caution:**

This unit is designed for a maximum of 2 children between the age of 3 to 10 years old on the motion rides. Maximum weight for each seat -110lb.

**Warning!**

Please read this instruction manual before you start with the assembly or use this swing set. You must follow all safety instructions while using this equipment; be absolutely sure that the surface on which this swing set is set up on, is properly surfaced with fine sand, and wood chips. Do not use this swing set on hard pack soil, concrete or any kind of hard surface. Read all cautionary statement before using this equipment.

- 
- 1. This play GYM must be assembled by an adult and make sure all the nuts and bolts were screwed tightly.**
  - 2. This play GYM can be used indoor or outdoor, but if used indoor please make sure there is sufficient space for it (3M from each leg).**
  - 3. This play GYM can be used on general ground, lawn or concrete floor, our recommendation is lawn. (Pay attention to the method of fixing it on different surface).**
  - 4. This unit must be used under the supervision of adult.**
  - 5. Not suitable for children under 3 years due to small parts.**

## **SAFETY INSTRUCTIONS**

Please follow these instructions carefully and keep them for future reference.

- 1) The equipment must be assembled by an adult.
- 2) Adult supervision is required at all times when using this product.
- 3) Age recommendation: 3 To 10 years of age.
- 4) Maximum weight for each seat is 110lb.
- 5) Recheck screws and nuts if properly tighten.
- 6) Make sure the bolts are protected by rubber caps.
- 7) Use the equipment only in an open area, Free from obstructions that could harm a child.
- 8) Use the equipment on a flat grassy surface. Patios, concrete or other hard surfaces must be avoided.
- 9) Children must be shown how to use this product safely. Do not let children climb all over the equipment or do roll over on the end frame. This practice can cause serious injury.
- 10) The seat surface of the swing shall not be higher than 600mm from the ground. The swing is use for sitting only and not for standing.
- 11) Suspension systems, Anchor points and fixings must be checked regularly for wear and tear and replaced where necessary.
- 12) Ropes must be replaced every 12 months if necessary.
- 13) Paintwork should be checked regularly and if necessary can be touched up using a non-toxic enamel or "CAR" type paint.
- 14) It is indispensable that the legs are concreted into the ground. If this is not possible, then the ground anchor provided must be used instead.
- 15) Do not leave young children unattended while playing on the equipment.
- 16) For family domestic use only.



**ASSEMBLING THE PLAY**

**GYM:**


Model. *SPSE-1575-2*

**PACKAGE CONTENTS / DIAGRAMS FOR PARTS:**

**1. CARTON PACK ( F Screws bag)**



PART NO	NAME	Q'TY
1	Top Support Bar (A)	1
2	Side Girt (With Safety Cap)	2
3	Leg (Upper)A	2
4	Leg (Upper) B	2
5	Leg Lower	4
6	Ground Anchor	4
F15	M8x45Hex Bolt	4

PART NO	NAME	Q'TY
F2	M6X40 Hex Bolt	4
U1	M6 Safety Nut	4
U2	M8 Safety Nut	4
X3	M6 Iron Wascher	4
X4	M8 Iron Wascher	4
Z1	Spanner	1
Y1	M6 Hex Wrench	1
Y2	M8 Hex Wrench	1



## ASSEMBLY INSTRUCTION FOR THE 1 UNIT OUTDOOR PLAYGYM

Do not fully tighten the screws when assembling the swing set. Please wait until the unit has been completely assembled and then fully tighten all screws.





- A. Insert Leg Upper (3) and Leg Upper (4) into Top Support Bar  $\frac{3}{4}$ , secure with Hex Bolt (F15), M8 Washer (X4) and M8 Nuts (U2).
- B. Insert Leg Lower (5) into Leg Upper (3) and Leg Upper (4) attach Side Girt (With Safety Cap (5) to Leg Upper (3) and Leg Upper (4) using Hex Bolt (F2), M8 washer (X3) and M8 nut (U1).

## 2. SWING ACCESSORY (A Screws bag)

PART NO	NAME	Q'TY
1	Swing Seat & Rope	1
X2	M8 Iron Washer	4

PART NO	NAME	Q'TY
G4	M8 U-Screw	2
U2	M8 Safety Nut	4



THE SEAT IS NO MORE THAN 400MM  
HIGH FROM THE GROUND

1: Hang two swing set & Rope(1) onto U-screw (G4), then assemble the U-screw onto the top support bar, fasten them with safety nut (U2) and washer (X4). Adjust the swing rope (1) to ensure the swing's balance and the height of the seat should be no more than 400 mm from the ground.

## **CARE AND MAINTENANCE**

This swing set was designed and manufactured with quality materials and craftsmanship. With proper care and maintenance, it will provide all players with years of exercise, fun, and enjoyment. Please follow the guidelines below:

This swing set is designed to withstand a specific weight and usage. Child over 110 pounds (50kgs) should not use the swing set. Players should remove all sharp objects from their person prior to using the swing set. All sharp or pointed objects should be kept off the playground at all times.

Always inspect the swing set before each use for worn, damaged or missing parts.

Please be aware of:

Loosed or missing bolt

Sagging support top bar

Bent or broken frame parts, such as the support leg

Broken, missing, or damaged seats

Damaged, missing, or insecurely attached rope

Protrusions of any types (especially sharp types) on the frame or any other places,

**IF YOU FIND ANY OF THE PREVIOUS CONDITIONS, OR ANYTHING ELSE THAT YOU FEEL COULD CAUSE HARM TO ANY USER, THE SWING SET SHOULD BE DISASSEMBLED OR SECURED FROM USE UNTIL THE CONDITION(S) HAS BEEN RECTIFIED.**





