

FOLDABLE MINI TRAMPOLINE

Manual



JYFM38"---DIA 96CM

JYFM40"---DIA 101.6CM

JYFM48"---DIA 121.92CM

JYFM55"---139.7CM

Please read these instructions carefully. The instructions are an integral part of the product. Therefore, please store them and the packaging carefully in case questions arise in the future. Please always include these instructions when you are handing on the product to a third-party. Children should only assemble, use or repair the product when they are under adult supervision.

Part list


ITEM NAME PART NAME	JYFM38"	JYFM40"	JYFM48"	JYFM55"
Frame tube	4 pcs	4 pcs	4 pcs	4 pcs
Jumping mat	1 pc	1 pc	1 pc	1 pc
Safety pad	1 pc	1 pc	1 pc	1 pc
Leg tube	6 pcs	6 pcs	8 pcs	8 pcs
Tube cover	6 pcs	6 pcs	8 pcs	8 pcs
Safety cover	6 pcs	6 pcs	8 pcs	8 pcs
spring	32 pcs	36 pcs	44 pcs	48 pcs
screw	4 pcs	4 pcs	4 pcs	4 pcs
Screw cap	4 pcs	4 pcs	4 pcs	4 pcs
Washer	8 pcs	8 pcs	8 pcs	8 pcs

Installation instructions and information:

- 1、 Keep children away from the folding trampoline during the installation process.
- 2、 Do not touch the ends of the frame components with your fingers while unfolding the folding trampoline. The folding trampoline will lock into the unfolded position. If fingers are caught between the ends of the frame components, pinching may cause serious injuries.
- 3、 If you let go prior to the frame components having locked into place the frame components will go back into the folded up position while you are unfolding the folding trampoline.
- 4、 The folding trampoline should always be unfolded or folded by two or more strong individuals.

Prior to installation, cross check all springs. These have been pre-installed by the factory. If one of the springs is not attached or appears to be damaged, please perform the following steps to secure the spring or exchange it:

- A. Hook the open end of the spring into the hole on the panel. See figure A.
- B. Turn the spring in the direction of the trampoline. See Figure B.
- C. Slide the metal bow on the mat over the spring hooks as shown in figure C.




Step 1.

Place the trampoline on the ground and open the frame components. The trampoline should look exactly as shown in figure 1



Step 2.

Hold the frame components while pressing down the frame components to unfold the trampoline in a flat position.



Warning: do not allow your fingers to touch the end of the panels in the hinge-joint areas while you are folding or unfolding the trampoline. If your fingers get caught between the ends of the panels, pinching can cause serious injuries !

Step 3:


Push the safety padding over the panel frame, make sure the holes in the safety padding are perfectly aligned with the screw connections of legs . See figure 3.



Note: place the opening over the screw connector and repeat this step for the screw connection on the opposite end of the trampoline.

Step 4:

Screw the six legs into the screw connectors on the panel frame. See figure 4.



The safety padding must be securely connected with the frame before the trampoline may be used. The trampoline must be placed firmly on the ground as showing in figure 5.



Step 5:

Place the trampoline into its normal position suitable for its used. Make sure that the safety padding covers the springs of the folding trampoline. Stand on the trampoline to make sure that all six legs are placed straight on the ground. See figure 5.

Safety warnings:

Paralysis or death can result if you land on your head or neck!

Do not perform somersaults (flips) as this will increase your chances of landing on your head or neck!

The trampoline must be used only on level, firm ground. If you are exercising in interior rooms, make sure that you have ample space around you. So that you will not bump into furnishings while exercising. In particular, make sure that you have sufficient clearance to the ceiling or lamps. We are recommend a slide distance of at least 1.5m and a safety clearance to the ceiling of 0.5m (head clearance to ceiling while jumping). Insufficient clearance may result in dangerous head injuries.

The trampoline may be used anywhere as long as it is set up on level ground and enough head clearance is provided. Make sure that no objects with sharp or pointed edges are located in the vicinity of the trampoline.

Sufficient light is critical while exercising to allow you to see the center of the trampoline without any problems. Never jump on the sides of the cover.

Prior to any use of the folding trampoline, check the correct attachment of the safety padding.

The support legs of your trampoline have beenn fitted with anti-slip rubber feet. As is the case with any rubber material, the feet may leave color spots on the ground in some cases. To prevent spots, place a protective cocer over sufaces prone to discoloration and make sure that your trampoline is standing securely. The trampoline must always be used on level and firm ground.

Make sure your trampoline is in perfect technical condition. Do not used the device if you discover any deficiencies. Make sure defective parts are repaired immediatly. Do not perform technical modifications to the trampoline.

The trampoline is not a toy!

The trampoline must be used by one person at a time! Please note that it is approved for a maximum load of 100kg!

For optimum results, exercise without shoes and barefoot. Do not wear socks, given that these may cause you to slip on the trampoline. If you prefer wearing shoes while working out, make sure they have soft rubber soles and no heels. Make sure that your shoes do not have any sharp edges or tips as those can damage the trampoline.

Maintenance, care and storage:

Check the product for damage or traces of wear and tear before and after each use. Store the product in a safe place where it is protected from the elements, cannot be damaged, and can not injure anyone.

For your own safety, please use original spare parts only. These can be sourced from us. Do not make any structural changes.

If parts become damaged or if sharp edges or corners should develop, the product may be not used any more. If in any doubt, please contact our service team.

Store the trampoline in a dark area and protect it from dust and sharp objects. Clean the cloth material with a brush. All other parts may be cleaned with a damp cloth. Use the protective covers to protect windings from corrosion whenever the legs are not installed.

Disposal advice:

At the end of the product's life, please dispose of it at an appropriate collection point provided in your area. Local waste management companies will be able to answer your questions on this.

Service:

We make every effort to deliver faultless products. If faults do arise however, we put just as much effort to rectifying them.