

WARNING

IMPORTANT MESSAGE TO PARENTS:

This manual contains important information. For your child's safety, it is your responsibility to review this information with your child and make sure that your child understands all warnings, cautions, instructions and safety topics.

PRECAUTIONS:

Like any other moving products, scooter riding can be a hazardous activity and it is possible to get into dangerous situations. Be sure to read the entire manual before riding. In particular, pay attention to the following notices.

1. Always wear proper protective equipment, such as an EN 1080 or EN 1078 approved helmet, elbow pads, knee pads, long sleeve shirt, gloves, long pants.
2. Always wear fully enclosed shoes, making sure they are done up properly before riding. You must not ride barefoot or in sandals.
3. Only ride the scooter on flat and level ground. DO NOT use the scooter on wet and uneven ground with rocks or gravel. In addition, DO NOT use the scooter at dusk or night or in wet or icy conditions.
4. DO NOT ride the scooter with only one hand but with both hands. You must hold on to the handlebar with two hands tightly.
5. DO NOT make a short or sharp turn when riding the scooter, and DO NOT lay your body on the handlebar when making a turn, as the handlebar of the scooter can twist, and may cause loss of control.
6. DO NOT ride the scooter on slippery or wet ground, as PU wheels can slip out of control. Avoid streets and surfaces with water, sand, gravel, dirt, leaves, and other debris. Wet weather impairs traction, braking and visibility.
7. DO NOT ride the scooter on steep slopes, as it can damage the unit or cause brake failure. Riders must be careful when passing such areas. Avoid excessive speeds associated with downhill rides.
8. Avoid sharp bumps, drainage grates, and sudden surface changes. Scooter may suddenly stop.
9. To brake, press the brake pedal with your foot. Ensure the brake is functioning before use. The brake pedal may be hot after continuous use. DO NOT touch after braking as it may cause harm.
10. Turn the handlebar to left and right to make sure it works properly and smoothly. Also check if the handlebar is fixed sturdily before riding the scooter.
11. All children and preteens should ride with adult supervision at all times. The supervisor should inspect the scooter prior to starting to use, making sure all parts are fully assembled and tightened to prevent accidents.
12. Not to be used in traffic. Always follow and obey all local traffic & scooter riding laws and regulations. Stay away from motor vehicles and watch out for pedestrians.
13. Use with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
14. DO NOT make any modifications on this product. DO NOT use any attachments that are not included with the scooter.
15. Due to the possible risk of pinching or entrapment while assembling the scooter, adults must assist children in the initial assembly & adjustment procedure. Keep fingers away from moving parts and all locking mechanisms during assembly as to not risk pinching or entrapping fingers and causing injury. Make sure all components are assembled and secured sturdily.
16. Injury may occur if the precautions above are not observed.
17. Replace worn and/or broken parts immediately.

CHECK BEFORE RIDING

First of all, please make sure the brakes function properly.

Secondly, check whether the handlebar is secured properly and tightly.

Thirdly, check the wheels are secure but still able to roll without resistance.

Finally, you can start riding the scooter after checking the above points and safety notices.

USER GUIDE AND MAINTENANCE

1. Please rotate the bearings and wheels to see whether they are workable, and do some adjustments or add lubricant if it's needed after the first 2 week's use.
2. In general, it is suggested to disassemble and clean the scooter every 6 months, and add lubricant on moving parts.
3. If the front fork and wheel are not fixed tightly, you can use a wrench to tighten the locking nut properly. Use firm pressure but avoid over tightening.
4. The wheels and wheel bearings may become worn out after regular use and can be changed easily. Remove the axle bolts with two allen keys and slide the wheel off its fork. Replace new wheel or wheel bearings, screw in the bolt through aligned fork and wheel, and then tighten the bolt with two allen keys on each side of the wheels. Acquire the correct wheels or wheel bearings from the local dealer of this scooter.
5. Wipe with a damp cloth to remove dirt and dust. Do not use industrial cleaners or solvents as they may damage the surfaces. Do not use alcohol, alcohol-bases or ammonia-bases cleaners as they may damage or dissolve some components or soften the decal adhesive.
6. Make sure all components are assembled and secured sturdily before each use.
7. Replace worn or broken parts immediately. Self-locking nuts and other self-locking fixings may lose their effectiveness over time. If any of these components are no longer functioning how they should be it is strongly recommended that you discontinue use of the product and seek replacement parts from the dealer or importer of this product.
8. Regular maintenance enhances the safety of the scooter.



