


ELECTRIC AIR PUMP

READ THE FOLLOWING INSTRUCTIONS AND WARNINGS BEFORE USE



IMPORTANT

The Power supply must be AC 230V, 50Hz. This pump is intended to inflate items such as airbeds, inflatable boats...etc, do not operate continuously for more than 20 minutes, as it may cause overheating or damages to the unit, take 10 minutes break before you use it again. Risk of electric shock, do not operate under moist conditions, and store indoors. The sound pressure level is about 87 dB (A). Keep this air pump away from the reach of children.

WARNING

1. Never attempt to disassemble or close to the openings while pump is operating.
2. Carefully follow instructions on items being inflated. Never exceed recommended pressures or do not over inflate. Over inflation may result in bursting of the item, possibly causing serious injury to yourself or others near by.
3. The supply cord cannot be replaced. If the cord is damaged the appliance should be scrapped.
4. Never leave pump unattended while in use. Do not use under wet conditions.
5. Never allow sand, small rocks, etc. to be sucked into inflation or deflation port while operating.
6. Never look into or point the inflate opening toward your eyes while pump is operating.
7. Do not attempt to put hand or fingers into the inflation or deflation part at any time.
8. **CAUTION:** To reduce the risk of electric shock, do not expose to rain. Store indoors.
9. This appliance is not intended for use by persons (including children) with

reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

10. Children should be supervised to ensure that they do not play with the appliance.

OPERATION

To Inflate

1. Insert the pump inflation port into the valve of the item.
2. Plug the power cord into the household AC electrical outlet.
3. Press the switch "I" to start inflation. When fully inflated, press "O" to stop inflation and disconnect the power supply cord.

NOTE: On larger items like inflatable boats and large air mattresses, the pump will fit directly into the inflation valves and provide faster inflation times. Use the appropriate adapter on small inflation valves as on small air mattresses, etc.

To Deflate

1. Open the air valve on the product items from which the air will be release.
2. If it required, insert the pump deflation port into the valve of the item.
3. Plug the power cord into the household AC electrical outlet. Press the switch "I" to start deflation.
4. When fully deflated, press "O" to stop and disconnect the power supply cord.

NOTE: On small inflation valves, the valve may have to be "pinched" with your fingers to open the flapper inside the valve and allow the air to escape.

WEEE- Disposal Information

1. Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
2. Contact your local government for information regarding the collection systems available.
3. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.
4. When replacing old appliances with new one, the retailer is legally obligated to take back your old appliance for disposal at least for free of charge.